



Compact, Accurate Counting

Kirby Lester KL1

Capsa Healthcare provides the Kirby Lester KL1, with world-renowned counting accuracy inside.

- Saves time: Faster and more accurate than manual counting.
- Compact design, fits into any crowded workspace.
- Inventory mode: keeps count when tray is emptied; count capacity of 9,999 tablets.
- Ergonomic tray with left/right pouring.
- No calibration needed; counts almost any tablet or capsule.
- Simple to clean.
- Ideal check-counter for Pharma/Industrial QC.

Equip Your Staff

with the perfect device to make Rx filling and inventory sessions effortless.



KL1 video



Speeds counting by up to 55%

The **KL1** is ideal for all prescription filling, from 30-counts to 90-day fills, and inventory (especially narcotics).



Ergonomic tray allows quick pouring from the left or right side.



KL1 Highlights

Preferred Counting Technology: Best-selling counting device worldwide. Easier and faster to use than outdated scales and cumbersome tray-and-spatula methods.

Fast: KL1 handles a 60-count Rx an average of 6.3 seconds faster than hand-counting, and 14.3 seconds faster for a 90-count Rx. Throughput up to 15 tablets/second.

Essential Inventory Tool: Maintain absolute inventory accuracy, especially for controlled medications (manual counting methods are only 95% accurate at best).

Free Up Time, Redeploy Staff: Using Kirby Lester counting technology frees up valuable time for customer service and profit-driving initiatives.

Ask about the KL1Plus

to add scan-verification, C-II log, and a record of each Rx





Compact, Accurate Counting

Kirby Lester KL1

- **Function:** Efficient tablet counter for pharmacy, and batch-counting/QC for manufacturing settings
- **Counting:** Counts almost all non-translucent oral solid medication, and many manufactured items
- **Throughput:** Up to 15 tablets/capsules per second
- **Dimensions:** 14.6" H x 12.5" D x 5.6" W (37.1cm x 31.75cm x 14.2cm)
- **Weight:** 6.95 lb (3.2kg)
- **Tray Capacity:** 800cc (max capacity approx. 1,450 ibuprofen 200mg round tabs)
- **Tray Pouring:** Left or right opening
- **Count Capacity:** Up to 9,999
- **Special Mode:** For counting items with odd shapes or holes
- **Maximum Tablet Size:** 0.86" long (22mm) and 0.74" wide (19mm)
- **Minimum Tablet Size:** 0.125" smallest diameter (3.175mm)
- **Inventory Mode:** Ideal for large counts; maintains the count while the tray is being emptied
- **Pharmacy Management Software Interface:** N/A
- **Power:** Standard wall outlet, 110V / 220V / 240V, 60Hz / 50Hz (no adjustments needed)
- **Vial Size Indicator:** Recommends vial size (drams) based on what was poured through
- **Cleaning & Maintenance:** Once-a-day cleaning recommended
- **CSA, CE:** Meets all standards
- **Warranty:** 1 year from ship date



Kirby Lester is pharmacy automation by Capsa Healthcare, a comprehensive solutions leader in managing the delivery of medication, patient information, and medical supplies. Capsa's diverse products are deployed globally in all types of pharmacies: retail, long-term care, hospital inpatient and outpatient, central fill and mail order.